

INSTRUCTION MANUAL

CONTENTS:

- 1 x DRIFT GT 1:10 Electric Remote Control Drift Car
- 1 x RC Transmitter
- 1 x Transmitter Antenna
- 1 x Tube for Wire Antenna
- 1 x Ni-Cd 700mAh 9.6V Rechargeable Battery Pack
- 1 x 9.6V Wall Charger
- 1 x 9V Battery
- 1 x Instruction Manual

BATTERY REQUIREMENT:

Vehicle: 1 x Ni-Cd 700mAh 9.6V Rechargeable Battery Pack (INCLUDED)
Transmitter: 1 x 9V Battery (INCLUDED)

CHARGING THE BATTERY PACK:

1. Plug the wall charger into a wall outlet
2. Connect the rechargeable battery pack to the wall charger
3. Charge for a maximum of 4 hours.


BATTERY WARNING:

1. Do not charge the battery for over 4 hours or over night. Over charging the battery will ruin the batteries ability to hold a charge.
2. Do not charge the battery without supervision.

INSTALLING OR REPLACING THE BATTERIES:


FOR TRANSMITTER:

1. Open the battery cover.
2. Install a 9V battery with the correct polarity (+/-) as shown inside the battery compartment.
3. Close the battery cover.




FOR VEHICLE:

1. Switch the power OFF.
2. Remove the battery cover.
3. Install the rechargeable battery pack by connecting the wires with the correct polarity.
4. Replace the battery cover.



HOW TO DRIVE THE RC VEHICLE:

1. Install the antenna to the top of the transmitter by twisting it clockwise.
2. Install the plastic tube for the vehicle antenna by passing the wire antenna through the plastic tube.
3. Switch ON the vehicle and transmitter.
4. Drive the vehicle FORWARD by squeezing the trigger and push the trigger to go BACKWARD.
5. Twist the wheel left and right to turn the car LEFT and RIGHT.
6. If the vehicle does not run in a straight line, adjust the wheel alignment on the vehicle chassis on the bottom of the vehicle by using a screwdriver.
7. Remember to switch OFF the vehicle and transmitter when you are done driving.



DRIVING TIPS:

1. Do not drive on grass, drift, sand or drive through water.
2. Do not drive the RC vehicle in poor weather conditions.
3. Do not crash the RC vehicle into hard objects.
4. Switch off the power to the transmitter and vehicle when not in use.
5. Keep fingers, hair and loose clothing away from the wheels.
6. Operating range of the transmitter can be affected by a variety of factors:
 - a) Weak batteries in the vehicle and/or transmitter.
 - b) Interference from other items that emit radio frequency signals such as another RC item on the same frequency, CB radios, cordless phones, high voltage transformers, etc...
7. To get the best range from the transmitter, operate the RC car outdoors.

BATTERY TIPS:

1. Alkaline batteries are recommended to use in the transmitter.
2. Only batteries of the same or equivalent type as recommended are to be used.
3. Do not mix alkaline, standard or rechargeable batteries.
4. Do not mix old and new batteries or different types of batteries.
5. Do not recharge non rechargeable batteries.
6. If rechargeable batteries are used, only charge them under adult supervision.
7. Rechargeable batteries are to be removed from the vehicle before they are charged.
8. Be sure to insert the batteries with the correct polarities and always follow the battery manufacturer's instructions.
9. Remove all batteries from the vehicle and transmitter when not in use.
10. Remove exhausted batteries from the product.
11. Do no short circuit the supply terminals.
12. Dispose of batteries properly. Do not dispose of batteries in fire - it may cause the battery to explode or leak causing injury or damage.
13. Battery change must be only made by adults.

WARNING:

1. Do not disassemble the RC vehicle or transmitter.
2. Do not operate the vehicle with the same frequency with other RCs in the same location. The same frequency RC will cause interference and you will lose control of the vehicle.
3. Make sure the batteries are installed with the correct polarity (+/-) as shown inside the battery compartment.

TROUBLE SHOOTING

PROBLEM	CAUSE	CORRECTION
RC Vehicle is unresponsive.	Low battery level Batteries are inserted incorrectly The wheels are obstructed by foreign objects Vehicle is out of range from transmitter	Charge the battery pack Insert the batteries with the correct polarities as shown on the battery compartment. Remove foreign objects from the wheels Move closer to the vehicle
Vehicle drives slow/poor turning.	Low battery level The wheels are obstructed by foreign objects	Charge the battery pack Remove foreign objects from the wheels
Poor remote control range	Low battery level Strong radio interference from surroundings	Charge the battery pack Move to a better location with less radio interference.

FCC Label Compliance Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
This device may not cause harmful interference.

This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Website: www.worldtechtoys.com
Email: customerserv@worldtechtoys.com
Phone: (877) 498-8697
Monday - Friday / 9:00AM - 5:00PM / Pacific Time